

TOOL-LESS BUTTPAD HEIGHT MECHANISM

Tools required: 3mm hex wrench

Fits: Separate versions for: X-ray Chassis,
Bravo Chassis, 180-Alpha Chassis

